



Orifice Mounting Instructions:  
 Recommended torque: 7 Nm / 5.2 lbs×ft.  
 Use anti-seize lubricant.

Orifice size	Ordering Code
Ø0,5	RT-060-050
Ø0,6	RT-060-060
Ø0,7	RT-060-070
Ø0,8	RT-060-080
Ø0,9	RT-060-090
Ø1,0	RT-060-100
Ø1,1	RT-060-110
Ø1,2	RT-060-120
Ø1,3	RT-060-130
Ø1,4	RT-060-140
Ø1,5	RT-060-150
Ø1,6	RT-060-160

Strainer Insert		
Connection Type D	R	H
Ordering Code	FIL-SI-6,0-06	FIL-SI-6,8-0,6

Material		Issue	Material Code No.
Changes		Date	Name
			Finish
			Break all edges
			Hardening depth
			HV
Designer	Leif Hansen	Scale 1:1	HC3-_-_-F
Approved by	<i>Leif Hansen</i>	Format A3	Orifice & Strainer Insert Positions
Date	02-05-2024	⚙️	Assembly Drawing
			<small>Confidential: Property of miniBOOSTER HYDRAULICS A/S Denmark          Not to be handed over to, copied or used by third party.</small> 
			Drawing No.: 3-916-00